

## CONQUEST FLOOR SWEEPER DAILY CHECKLIST

*(Guide only diesel operated sweepers)*

Operator has read and understood operator and maintenance manual

Check area the sweeper is to be used in is in accord with "Permissible conditions of use"  
(Free from debris, large slopes and other dangers)

Visually check over sweeper:

Diesel fuel tank

Oil level

Coolant level

Side skirts

Motor

Controls

Seat

Wheels

Check hand brake is on before starting

Turn key to start, wait till glow plug light goes out then start machine and warm motor  
for 30 seconds check operation

Use machine in accord with operator and maintenance manual

Empty hopper after every use

Shake filter clean after every use

Idle down unit for 15 seconds before switching off

Turn machine off

Pull up hand brake

**All inquiries 1800 826 789**

Parts inquiries:

[parts@conquestequipment.com.au](mailto:parts@conquestequipment.com.au)

Service inquiries:

[service@conquestequipment.com.au](mailto:service@conquestequipment.com.au)